

Standard Operating Procedure Refuse Disposal Division



Greens Processing

Morbark Trommel Screen Startup/ Lockout

Startup Procedure:

- 1. Notify all affected persons of the machine start-up and clear the area of unauthorized persons.
- 2. Make sure conveyor belts are in NEUTRAL.
- 3. Make sure the Trommel is clear.
- 4. Signal horn 3 times.
- 5. Turn master switch ON.
- 6. Start engine and warm-up for 5 minutes.
- 7. Turn all conveyors ON.
- 8. Turn end conveyor levers ON.
- 9. Clear Trommel antennae and turn remote ON.
- 10. Build up RPMs.
- 11. Adjust to Trommel speed for optimum material output.
- 12. Adjust load belt for optimum output.

Lockout Procedure:

- 1. Notify all affected persons of the machine lockdown and clear the area of unauthorized persons.
- 2. Visually inspect the screens to verify that there is no debris lodged.
- 3. Load to SLOW.
- 4. Trommel to SLOW.
- 5. Throttle down (allow 5 minutes for cool down).
- 6. Stop engine.
- 7. Conduct a walk-around of the equipment to ensure area is clear.
- 8. While doing the walk-around, turn OFF the conveyors.
- 9. Turn OFF the master switch and put the key in your pocket.
- 10. Lockout the conveyor levers and put the key in your pocket.
- 11. Take the remote with you to perform service.

Sequence of Removal of Lockout:

- 1. Notify all affected persons of the lockout removal.
- 2. Remove the lock from the conveyor controls and follow startup procedure above

Benefit of Compliance to Instruction:

- Ensure a safe working environment for all personnel
- Create a marketable product
- Generate consistent material output

Consequence of Non-Compliance to Instruction:

- Probable contamination of product
- Material output significantly lower due to incorrect feed and Trommel speed
- Possible injury due to unsafe lockout procedure

Reviewed by: Mark zu Hone, *EMR*

Approved by: Gary Gobel, *Greenery Supervisor* Date: March 15, 2001

The on-line version and secured hardcopy are the controlled documents. The secured hardcopy will be identified by a "Controlled Copy" stamp (in red) and RDD Deputy Director signature. Any other documents are uncontrolled. Verify revision level status on-line or contact the EMR.

PROCESS MAP #: GP-1.0